

FLUID SAMPLING SET WITH VACUUM PUMP FOR QUICK AND CLEAN OIL SAMPLING

REUSABLE FLUID SAMPLING SET



The quality of sampling is crucial for the result of an oil analysis.

Please use a new suction hose and a clean sample bottle for every oil sample taken. In this way you can be sure that the contaminants come only from the oil sample taken and that the analysis results have not been distorted.



Ask your HANSA-FLEX customer adviser about it now

Or contact any of our around 200 HANSA-FLEX subsidiaries in Germany

TAKING SAMPLES WITH THE HANSA-FLEX VACUUM PUMP

1. Thoroughly clean the area around the sampling point. This will avoid or minimise the effects of any contaminants present on the surrounding surfaces.
2. Screw the appropriate adapter onto the HANSA-FLEX vacuum pump. Use the DIN 38 adapter for sample bottles with a DIN 38 thread. Use the DIN 55 adapter for sample bottles with a DIN 55 thread.
3. Take a sample bottle and screw the glass onto the vacuum pump.
4. Release the pinch clamp on the pump and push the hose through the head of the pump until the hose end projects approx. 1 cm into the sample bottle. Make sure you close the pinch clamp so that it holds the hose securely.
5. Place the other end of the hose into the sampling point. Do not allow the hose to stand on the bottom of the sampling point.
6. Pump the oil with approximately 3–6 complete pump strokes (depending on the size of the sample bottle) into the sample bottle. Ensure that the sample bottle remains upright during the whole of the sampling process and is not overfilled.
7. Carefully unscrew the filled sample bottle off the adapter and seal the bottle with the lid.
8. Dispose of the used hose piece in accordance with the applicable regulations. The HANSA-FLEX vacuum pump and adapter remain clean and can be reused as often as required.

Please use the approved oil analysis sets from HANSA-FLEX for oil analyses performed in a laboratory. These sets already contain the shipping case and a plastic transport container. All oil samples will be evaluated within 48 hours of receipt at the laboratory.

You can find the fluid sampling set with vacuum pump in our shop www.shop.hansa-flex.de



Direct link to
the product

